PS:
：車身前端接地
：車身前部接地
：車身後端接地
：引擎接地
：容許加可攜電池

FLASHER
HAZARD S/W
DIRECTION INDICATOR S/W
DIODE
LAMP ASSY, DIRECTION INDICATOR, FL 10W
LAMP ASSY, DIRECTION INDICATOR, FR 10W
HEAD HI FUSE 15A
HEAD LO FUSE 15A
HEAD LIGHT SWITCH
HEAD LIGHT RELAY (HI)
HEAD LIGHT RELAY (LO)
OTHER LIGHT RELAY
HEADLAMP ASSY, L 55W 55W
HEADLAMP ASSY, R 55W 55W
LAMP LICENCE PLATE 5W
Fuse
Fuse
SWITCH-BREAK/FOOT 3.5A
SWITCH-BREAK/HAND (R) 3.5A
SWITCH-BREAK/HAND (L) 3.5A
LAMP ASSY, REAR COMB, L 10W 5W 21W
LAMP ASSY, REAR COMB, R 21W 5W 10W
I.D. LAMP-L
I.D. LAMP-R
CONNECT A TRAILER FOG-LIGHT ON ATV MUST GO DOWN
LAMP-BREAK 21W×2
LAMP-FOG 21W
LAMP-LICENCE PLATE 5W
LAMP-POSITION 10W
SW#1
SW#2
2.1W LED-FOG LAMP
Fog indikator Light

DIFF. CONTROL UNIT (DCU)
Diff. Control Relay
P/G RPM (ALT)
Diff. Lock Lamp Control Relay
Ext Input
Pwr. Power
Lock-Position Input
Diff. Motor Power Input
Signal Input
DIFF. LOCK SWITCH
DIFF. LOCK MOTOR(F)
DIFF. LOCK MOTOR(R)

SPEED SENSOR
FLOAT-FUELPUMP
SPEEDMETER
DIODE
2/4WD LEVEL POSITION
OIL/P. S/W
GEAR POSITION

POWER SOURCE FUSE 10A
20A
POWER SOURCE
HORN SWITCH 3.0A
HORN 36W
FAN FUSE 15A
THERM-OSTAT
FAN RELAY
COOLING FAN MOTOR 50W

RECTIFIER
IC
GENERATOR
WINCH-KEEP WIRE
STARTER RELAY
STARTER MOTOR
BATTERY 50A
IGN. S/W
ENGINE SWITCH
STARTER SWITCH

INJECTOR
COIL
O2 Heater
IGN KEY
IACV
FUEL PUMP
ENGINE& POWER SUPPLY RELAY
E/G FUSE 15A
F/P FUSE 10A
F/PUMP RELAY
VBB
GND_P

ECU (16bit)
TPS
COOLING TEMP.
INLET AIR TEMP.
O2 SENSOR
SENSOR-FUEL CUT
CRANK SNSR. FLY WHEEL
OVERRIDE SWITCH
CAN
K-LINE
DIAGNOSTIC TOOL

編修日期： 970311