



EBS00025

COOLANT FLOW DIAGRAMS

- ① Thermostat cover
- ② Fast idle plunger outlet hose
- ③ Radiator inlet hose
- ④ Radiator
- ⑤ Radiator outlet hose
- ⑥ Water pump breather hose
- ⑦ Water pump

- [A] Install the radiator inlet hose onto the thermostat cover pipe, making sure that it contacts the cover and its yellow paint mark is facing outward.
- [B] Fasten the fast idle plunger outlet hose and the radiator inlet hose with the plastic band.
- [C] Install the radiator inlet hose with its white paint mark facing outward.

