


4GB1110-3180

4GB1110-3180

Fig. 17 SHIFT CAM & FORK

Ref. No.	Part No.	Part Name		Remarks
1	4GB-18540-00	SHIFT CAM ASSY	1	
2	4GB-18511-00	FORK, SHIFT 1	1	
3	4GB-18512-00	FORK, SHIFT 2	1	
4	4GB-18513-00	FORK, SHIFT 3	1	
5	4GB-18535-00	BAR, SHIFT FORK GUIDE 2	1	
6	4GB-18531-00	BAR, SHIFT FORK GUIDE 1	1	
7	93210-07590	O-RING	2	
8	90201-144J2	WASHER, PLATE	1	
9	1YW-18101-01	SHIFT SHAFT ASSY	1	
10	90508-32711	.SPRING, TORSION	1	
11	93102-14209	OIL SEAL	1	
12	1UY-18140-00	STOPPER LEVER ASSY	1	
13	90508-25712	SPRING, TORSION	1	
14	90109-063F7	BOLT	1	
15	4G0-18127-00	STOPPER, SCREW	1	
16	90215-08260	WASHER, LOCK	1	
17	1YW-18106-00	GUIDE SHIFT COMP. 2	1	
18	93342-21212	BEARING	1	
19	1YW-18181-00	HOLDER, PAWL	1	
20	1YW-18104-00	SHIFT GUIDE COMP.	1	
21	1YW-18318-00	SHAFT, SHIFTER	1	
22	1YW-18127-00	STOPPER, SCREW	1	
23	2VA-1817A-00	ARM, SHIFT 3	1	
24	21V-18126-00	PIN, LEVER	1	
25	21V-18118-00	PIN, JOINT	1	
26	92901-08600	WASHER, PLATE	1	
27	91401-16015	PIN, COTTER	1	
28	21V-18127-00	STOPPER, SCREW	1	



4GB1110-3180

© 1994 Yamaha Motor Co., Ltd.

Fig. 17 SHIFT CAM & FORK

Ref. No.	Part No.	Part Name		Remarks
29	93210-07590	O-RING	1	
30	90201-08649	WASHER, PLATE	1	
31	95316-08700	NUT	1	
32	90501-162E4	SPRING, COMPRESSION	1	
33	2HR-18546-06	CAM, SHIFT 2	1	
34	2HR-18311-00	FORK, SHIFT 1	1	
35	1YW-18312-00	FORK, SHIFT 2	1	
36	2HR-18323-00	CAP, SPRING	1	
37	90501-147E8	SPRING, COMPRESSION	1	
38	5Y1-18535-00	BAR, SHIFT FORK GUIDE 2	1	
39	93102-15212	OIL SEAL	1	
40	93503-08007	BALL	1	
41	90501-10353	SPRING, COMPRESSION	1	
42	90105-14367	BOLT, WASHER BASED	1	
43	90430-14194	GASKET	1	
44	2HR-18110-00	SHIFT PEDAL ASSY	1	
45	132-18113-01	.COVER, SHIFT PEDAL	1	
46	98016-06020	BOLT	1	